

cintropur[®]

WATER FILTRATION & TREATMENT



NW500 – 650 – 800 – 500TE

NW 500 – 650 – 800 – 500TE

Instructions for assembly, use and maintenance

1. Possible applications

The range of water filters CINTROPUR® NW 500-650-800-500TE is designed for filtering **clear water** slightly loaded with solid suspended particles, such as city water, rainwater, borehole water, spring water. Other types of non-aggressive liquids can also be filtered. The possible areas of use are in the industrial, the public and the agricultural sectors.

The materials used to manufacture the filters are suitable for **food products** and **drinking water**.

The use of the NW 500 TE with activated carbon is well known for dechlorinating, removal of odours, improvement of taste, reduction of pesticides and herbicides.

2. Technical description

The installation must be achieved according to the correct existing standards and by qualified personnel. These filters must be used in compliance with the technical requirements listed in the following table:

| | | NW 500 | NW 650 | NW 800 | NW500TE |
|---------------------------------------|-----------|----------------|----------------|----------------|----------------|
| Diameter of pipe | | 2" | 2 1/2" | 3" | 2" |
| Type connection | | External dread | Slip-on flange | Slip-on flange | External dread |
| Average flow rate (m ³ /h) | ΔP=0.2bar | 18 | 25 | 32 | 2* |
| | ΔP=0.5bar | 28 | 42 | 51 | 3.3* |
| Working pressure (bar) | | 10 | 10 | 10 | 10 |
| Max. operating pressure (bar) | | 16 | 16 | 16 | 16 |
| Maximum operating temperature | | 50°C | 50°C | 50°C | 50°C |
| Weight (kg) | | 6.4 | 7 | 7.4 | 5.6 |
| Standard filter sleeve | | 25 μ | 25 μ | 25 μ | - |
| Bowl volume (l) | | - | - | - | 4.85 |
| Filtration surface (cm ²) | | 1288 | 1288 | 1288 | - |

*value with activated carbon

3. Assembly and handling

- The ideal location for the CINTROPUR® water filter is directly at the point of entry (after the meter or after the pump). Make sure that the direction of the water flow corresponds to the direction of the arrow on the filter head.
- The filters must be fitted according to the state of the art procedures: they must be free of any mechanical stress, with the piping upstream and downstream aligned. The distance between the couplings must be correct to avoid any tension or compression stress on them.
- A pressure reducer will efficiently reduce the supply pressure if it exceeds the operating pressure. An anti-water hammer device is necessary in case it may occur on the installation.
- Equipment:
 - **Standard:** includes a set of 2 threaded connectors (NW 500 & 500TE) or a set of 2 slip-on flanges (NW 650 & NW 800), 2 pressure gauges (except the TE version), a 25μ filter screen fitted on its support, a purge valve and a spanner for disassembly.
 - **The possible options** are the opaque bowl, the stainless steel wall mount and the 2 flat sealing joints (for placing between the flange neck and the counter-flange).
 - The glycerine-filled **pressure gauges** supplied as standard (except on NW 500 TE) have a standard 1/4" thread; fitting is done using a spanner (the dial is not to be used as a handle for screwing it in!).
 - Fixing the stainless steel wall mount to the filter head is done using the 2 thumbwheels provided for this purpose. For normal use, hand-tightening these is adequate for a good hold.

- NW650 and NW800:
 - The filter is supplied complete and ready to install.
 - The flanges must be fitted off-axis (with the 2 upper holes in a horizontal line)
 - The flanges are compliant with DIN EN 1092-1 PN-10 with holes identical to EN 1092-1 PN-16.
 - The flange of the NW650 requires 4 M16 bolts, and the flange of the NW800 requires 8 M16 bolts.
 - These bolts should be made moderately tight:
 - NW650: flat seal for max. 10 bar 40 °C: 50 Nm.
 - NW650: profiled seal for max. 10 bar: 25 Nm.
 - NW800: flat seal for max. 10 bar 40 °C: 30 Nm.
 - NW800: profiled seal for max. 10 bar: 15 Nm.
 - Water tightness between the flange of the CINTROPUR® NW 650 & 800 and the counter-flange of the installation must be provided by a flat seal of type EPDM-PN10 or EPDM-PN16 of good quality (as an option from CINTROPUR or available in the trade).
 - The original supplied couplings must be used because the metric thread of the head is not compatible with other standard couplings of the trade. They are of size M76x2,8 in type NW 500-650 and M88x2,8 in type NW 800.
- NW500:
 - The union nuts to be screwed on are supplied separately in the packaging. When they are fitted it must be checked that the O-rings are present on the end pieces of the head where they will be screwed on.
 - The tightness of the threaded connections of the NW 500 can be achieved with any of the usual trade products. However, the hemp and paste from Kolmat is to be preferred. Leave one thread turn free on the filter connector to provide a good start for the valve or connector of your installation.
 - The original supplied couplings must be used because the metric thread of the head is not compatible with other standard couplings of the trade. They are of size M76 in type NW 500.
 - The tightness between the threaded connector and the filter head is ensured by a sealing ring; hand-tightening with two hands is sufficient for low pressures. For higher pressures, around 10 bar, tightening with a strap wrench is recommended. Checking the tightness is required when pressurising.
- NW500, 650 and 800:
 - The tightness between the head and the bowl is ensured by an O-ring: tightening lightly with the supplied spanner is adequate. The spanner is also used for disassembly.
 - The purge valve adapter (in the lower part) is factory-fitted with a double sealing joint. This adapter can rotate through 360° without damaging the bowl.
 - The cylindrical support of the filter screen is fitted at the 2 ends with a centrifugal spinner and a sealing cover. A holding screw fixes them to ensure complete sealing between the water to be filtered and the filtered water. A joint overmould has been implemented to this end. Handling of these fixing screws is done using only the hands (no tools).
 - Fitting isolating valves upstream and downstream is advised for assisting maintenance of the filter.
- NW500TE:
 - Filling the bowl of the NW 500 TE with the treatment material (activated carbon, polyphosphate etc.) is made easier by following the rules stated in the appendix.
 - The models NW650TE & NW 800 TE do not exist as finished products; they can be made by replacing the internal filtration parts by the "tube + strainer" device.

4. Maintenance

- Before disassembling the bowl, close the upstream and downstream valves and release the pressure.
- Filter screen:
 - Maintenance and replacement of the filter screen used for drinking water is recommended at least 3 times per year and in any case before the pressure loss reaches 2 bar.
 - The filters graded 1, 5, 10, 25, 50 & 100 μ are intended for a single use. Cleaning them would change the structure of the fibre, so degrading the fineness of the selected filtering and making the filter more fragile, which could lead to tearing.
 - The nylon filters graded 150 & 300 μ are designed to be cleaned and re-used.
- Activated carbon:
 - Replacement of the activated carbon in the NW 500 TE for drinking water is necessary every 90 m³, and in other cases at least every 3 months.
- Centrifugal spinner and cover:
 - The system for holding the centrifugal spinner on the cylindrical support is provided with 4 slots for correct positioning; take note of this before refitting.
 - Before refitting the sealing cover on the cylindrical support, ensure that the filter screen is not touching the cross of the internal reinforcement. Handle the fixing screws of the spinner and the cover only with bare hands (using a tool would cause damage).
- The bowl:
 - The thread of the bowl must stay clean and greased for easy fitting and removal of the bowl during its life time.
 - The sealing ring between the head and the bowl must also remain clean and greased for good sealing.
 - All slots and O-ring seatings (& flat joint) must remain clean and without burrs.
- Damaged component:
 - Every component of the filter, even if only slightly damaged, must be replaced immediately to ensure good performance under pressure and water-tightness of the whole filter.

5. Warranty

The choice of high-quality raw materials for manufacturing each component of your filter is the best guarantee of giving you full satisfaction for many years of use.

If, nevertheless, a component develops a fault related to a manufacturing defect, this would be covered by a replacement of that component under guarantee. For further information about CINTROPUR products, go to www.cintropur.com